



GREENSPOKE

BIKE PARKING SOLUTIONS


1-844-888-9999
www.gogreenspoke.com

Compact Vertical Rack System

Typical Assembly Method

Model Shown: CVR-S
Single Sided Floor Mount
4-Bike Unit

Rev.: 13Nov15



Assembly Order:

- 1) Attach Posts to Base Channels as shown.
- 2) Attach Horizontal Rail Weldment to Posts as shown.
- 3) Attach Hook Brackets to Horizontal Rails as shown.
(Hook Bracket Heights: 1st High, 2nd Low, 3rd High, 4th Low)

For Double Sided Units:

- 4) Attach Hook Brackets *WITHOUT* Weldnuts on Opposite Side of Hook Brackets *WITH* Weldnuts.